

XLC WARGAME TERRAIN

Remove backing film carefully before assembly.

Do not glue centre panel, so it remains removable

Assemble with PVA Wood glue - DO NOT use cyano / superglue.

